

BUILD YOUR OWN CLAY BRICK BIRD BATH



MATERIALS AND QUANTITIES

A. FOUNDATIONS	0.06m ³	B. CLAY BRICK WALLS	2.58m ²
1. Stone	0.05m ³	1. Clay Bricks	140
2. Sand	0.03m ³	2. Building Sand	0.14m ³
3. Cement	2/5 pocket	3. Cement	¾ pocket
C. EARTH FILLING		D. QUARRY TILES	16
		(152mm x 152mm)	
E. CEMENT TRAY			
(402mm x 402mm x 40mm)			

INSTRUCTIONS

Study Instructions and Drawings before starting

- Foundations 'A' 250mm(w) x 100mm (h)**
Set out the foundation lines 250mm apart. The outer lines should be 830mm long.
- Excavation**
Excavate between lines to depth of 250mm.
- Concreting 'A'**
Cast concrete foundation to 100mm height.
- Bricklaying 'B'**
Mark out brick lines on the foundation, and build the Clay Brick walls for 13-courses above the foundation.
- Earthfilling 'C'**
After two days, walls will be set and the cavity can now be filled with earth. Ram firmly to the bottom of the last brick course.
- Dish Base 'E'**
Cast concrete base ±50mm thick, so that when dish is inserted, its top is level with the top of the quarry tile capping.
- Quarry Tile Capping 'D'**
Carefully centralise position of the dish within the Clay Brick walls and lay the quarry tiles around it, allowing for a few millimetres all round to facilitate its removal.

